



Autafaster - AACC01-007 - CERRADURA CIERRE CENTRALIZADO

OEM

3B4839015AG

3B4839015AN

3B4839015K

5J0839015

6QD839015A

6Y0839015

6Y0839015A

6Y0839016

Lado

RL Atrás Izquierda

Lado Opuesto

AACC01-008

Referencia Autafaster

AACC01-007

OEM

3B4839015AG

3B4839015AN

3B4839015K

5J0839015

6QD839015A

6Y0839015

6Y0839015A

6Y0839016

Lado

RL Atrás Izquierda

Lado Opuesto

AACC01-008

Número de pines

6 pins

Modelos Aplicables corto

SEAT Ibiza III/Cordoba II SKODA Fabia I

Volkswagen Polo IV

Modelos Aplicables largo

SEAT

SEAT CORDOBA (6L2) 1.2 10/2002 - 06/2006
SEAT CORDOBA (6L2) 1.2 12V 05/2006 - 11/2009
SEAT CORDOBA (6L2) 1.4 16V 09/2002 - 12/2007
SEAT CORDOBA (6L2) 1.4 16V 05/2006 - 11/2009
SEAT CORDOBA (6L2) 1.4 16V 10/2002 - 11/2009
SEAT CORDOBA (6L2) 1.6 04/2003 - 11/2009
SEAT CORDOBA (6L2) 1.6 16V 11/2006 - 11/2009
SEAT CORDOBA (6L2) 2.0 09/2002 - 11/2009
SEAT CORDOBA (6L2) 1.4 TDI 05/2005 - 11/2009
SEAT CORDOBA (6L2) 1.4 TDI 10/2002 - 12/2005
SEAT CORDOBA (6L2) 1.4 TDI 06/2005 - 11/2009
SEAT CORDOBA (6L2) 1.9 SDI 09/2002 - 11/2009
SEAT CORDOBA (6L2) 1.9 TDI 09/2002 - 11/2009
SEAT CORDOBA (6L2) 1.9 TDI 10/2002 - 11/2009
SEAT IBIZA III (6L1) 1.2 06/2007 - 05/2008
SEAT IBIZA III (6L1) 1.2 02/2002 - 06/2006
SEAT IBIZA III (6L1) 1.2 12V 05/2006 - 11/2009
SEAT IBIZA III (6L1) 1.4 16V 02/2002 - 12/2007
SEAT IBIZA III (6L1) 1.4 16V 05/2006 - 11/2009
SEAT IBIZA III (6L1) 1.4 16V 02/2002 - 11/2009
SEAT IBIZA III (6L1) 1.6 02/2003 - 11/2009
SEAT IBIZA III (6L1) 1.6 16V 11/2006 - 11/2009
SEAT IBIZA III (6L1) 1.8 T FR 12/2003 - 05/2008
SEAT IBIZA III (6L1) 1.8 T Cupra R 01/2004 - 02/2008
SEAT IBIZA III (6L1) 2.0 04/2002 - 11/2009
SEAT IBIZA III (6L1) 1.4 TDI 05/2005 - 11/2009
SEAT IBIZA III (6L1) 1.4 TDI 05/2002 - 12/2005
SEAT IBIZA III (6L1) 1.4 TDI 06/2005 - 11/2009
SEAT IBIZA III (6L1) 1.9 SDI 02/2002 - 12/2005
SEAT IBIZA III (6L1) 1.9 TDI 02/2002 - 11/2009
SEAT IBIZA III (6L1) 1.9 TDI 02/2002 - 11/2009
SEAT IBIZA III (6L1) 1.9 TDI Cupra R 03/2004 - 02/2008

SKODA

SKODA FABIA I (6Y2) 1.0 12/1999 - 08/2002
SKODA FABIA I (6Y2) 1.2 07/2001 - 04/2007
SKODA FABIA I (6Y2) 1.2 01/2003 - 03/2008
SKODA FABIA I (6Y2) 1.4 08/2000 - 08/2002
SKODA FABIA I (6Y2) 1.4 08/1999 - 05/2003
SKODA FABIA I (6Y2) 1.4 16V 12/1999 - 03/2008
SKODA FABIA I (6Y2) 1.4 16V 12/1999 - 03/2008
SKODA FABIA I (6Y2) 2.0 12/1999 - 03/2008
SKODA FABIA I (6Y2) 1.4 TDI 04/2003 - 03/2008
SKODA FABIA I (6Y2) 1.9 SDI 12/1999 - 03/2008
SKODA FABIA I (6Y2) 1.9 TDI 01/2000 - 03/2008
SKODA FABIA I (6Y2) 1.9 TDI RS 06/2003 - 03/2008

SKODA FABIA I Sedán (6Y3) 1.2 07/2001 - 12/2007
SKODA FABIA I Sedán (6Y3) 1.2 01/2003 - 12/2007
SKODA FABIA I Sedán (6Y3) 1.4 04/2000 - 08/2002
SKODA FABIA I Sedán (6Y3) 1.4 07/2001 - 05/2003
SKODA FABIA I Sedán (6Y3) 1.4 16V 10/1999 - 12/2007
SKODA FABIA I Sedán (6Y3) 1.4 16V 12/1999 - 12/2007
SKODA FABIA I Sedán (6Y3) 2.0 12/1999 - 12/2007
SKODA FABIA I Sedán (6Y3) 1.4 TDI 04/2003 - 12/2007
SKODA FABIA I Sedán (6Y3) 1.9 SDI 11/1999 - 12/2007
SKODA FABIA I Sedán (6Y3) 1.9 TDI 01/2000 - 12/2007
SKODA FABIA I Combi (6Y5) 1.2 07/2001 - 12/2007
SKODA FABIA I Combi (6Y5) 1.2 01/2003 - 12/2007
SKODA FABIA I Combi (6Y5) 1.4 04/2000 - 03/2003
SKODA FABIA I Combi (6Y5) 1.4 04/2000 - 05/2003
SKODA FABIA I Combi (6Y5) 1.4 16V 05/2000 - 12/2007
SKODA FABIA I Combi (6Y5) 1.4 16V 04/2000 - 12/2007
SKODA FABIA I Combi (6Y5) 2.0 04/2000 - 12/2007
SKODA FABIA I Combi (6Y5) 1.4 TDI 04/2003 - 12/2007
SKODA FABIA I Combi (6Y5) 1.9 SDI 04/2000 - 12/2007
SKODA FABIA I Combi (6Y5) 1.9 TDI 04/2000 - 12/2007
SKODA FABIA I Praktik (6Y5) 1.2 07/2001 - 12/2007
SKODA FABIA I Praktik (6Y5) 1.2 01/2003 - 12/2007
SKODA FABIA I Praktik (6Y5) 1.4 07/2001 - 05/2003
SKODA FABIA I Praktik (6Y5) 1.9 SDI 07/2001 - 12/2007

VW

VW POLO IV (9N_, 9A_) 1.2 01/2002 - 05/2007
VW POLO IV (9N_, 9A_) 1.2 05/2007 - 11/2009
VW POLO IV (9N_, 9A_) 1.2 12V 10/2001 - 07/2007
VW POLO IV (9N_, 9A_) 1.2 12V 05/2007 - 11/2009
VW POLO IV (9N_, 9A_) 1.4 16V 10/2001 - 05/2008
VW POLO IV (9N_, 9A_) 1.4 16V 05/2006 - 11/2009
VW POLO IV (9N_, 9A_) 1.4 FSI 02/2002 - 07/2006
VW POLO IV (9N_, 9A_) 1.4 16V 10/2001 - 05/2008
VW POLO IV (9N_, 9A_) 1.6 16V 05/2006 - 11/2009
VW POLO IV (9N_, 9A_) 1.8 GTI 09/2005 - 11/2009
VW POLO IV (9N_, 9A_) 1.8 GTi Cup Edition 05/2006 - 11/2009
VW POLO IV (9N_, 9A_) 1.4 TDI 04/2005 - 11/2009
VW POLO IV (9N_, 9A_) 1.4 TDI 10/2001 - 06/2005
VW POLO IV (9N_, 9A_) 1.4 TDI 04/2005 - 11/2009
VW POLO IV (9N_, 9A_) 1.9 SDI 10/2001 - 11/2009
VW POLO IV (9N_, 9A_) 1.9 TDI 10/2001 - 11/2009
VW POLO IV (9N_, 9A_) 1.9 TDI 11/2003 - 11/2009
VW POLO IV Sedán (9A4, 9A2, 9N2, 9A6) 1.4 11/2002 - 04/2012
VW POLO IV Sedán (9A4, 9A2, 9N2, 9A6) 1.4 11/2003 - 06/2005
VW POLO IV Sedán (9A4, 9A2, 9N2, 9A6) 1.4 TDI 07/2003 - 06/2005
VW POLO IV Sedán (9A4, 9A2, 9N2, 9A6) 1.9 SDI 09/2002 - 04/2012











THE FUNCTION OF THESE CONTROLS ARE AS FOLLOWS: WHEN THE
ENGINE IS RUNNING, THE CONTROLS ARE IN THE "ON" POSITION.
WHEN THE ENGINE IS STOPPED, THE CONTROLS ARE IN THE "OFF" POSITION.
WHEN THE ENGINE IS STOPPED, THE CONTROLS ARE IN THE "OFF" POSITION.





